



SFP 512

Conventional Fire Alarm and Extinguishing Panel
EN 54-2, EN 54-4 and EN 12094-1

 **SECURITON**

Für Ihre Sicherheit

SFP 512

Product Features

- Easy handling
- 4 zone conventional fire alarm panel
- Expandable up to max. 12 detection zones
- Optional extinguishing module
- Optional relay output module 4 or 12 relays
- SecuriStar optical and heat detectors
- Up to 32 detectors and 2500m per line
- Complies with EN 54-2 and EN 54-4
- Complies with EN 12094-1
- Languages: English, Italian, Spanish, Portuguese, NL
- Power Supply 230V/50Hz < 75W
- Batteries 2x7.2 Ah, max 0.95 A



Inputs & Outputs main card

Inputs

- 1 Programmable monitored input (3 options)
 - External reset
 - Monitoring of external power supply activation of the “Power Supply Fault” LED
 - Evacuation → activation of the sounders line

Outputs

- 24VDC / 400 mA
- 1 General Alarm Relay Output
- 1 General Fault Relay Output
- 1 Open collector output for each zone (alarm)
- 1 Monitored sounder line

Inputs & Outputs Extinguishing card

Inputs:

- Manual Extinguishing Trigger
- Manual Extinguishing Stop
- Gas loss (monitored)




Outputs:

- Extinguishing Valve (monitored)
- Sounder for Evacuation (monitored)

SFP 512

Structure



Extension Modules:


<u>Panel configuration</u>	<u>Modules</u>
➤ 4 fire alarm lines	SFP512
➤ 8 fire alarm lines	SFP512 + 4Z
➤ 12 fire alarm lines	SFP512 + 4Z + 4Z
➤ 4 fire alarm lines + 1 extinguishing zone	SFP512 + Ext1
➤ 4 fire alarm lines + 2 extinguishing zones	SFP512 + Ext1 + Ext1
➤ 8 fire alarm lines + 1 extinguishing zones	SFP512 + 4Z + Ext1
➤ All the above configuration can be equipped additionally with a relay card:	4R or 12R

Extension Modules:

Fire line extension

- 4 zone detection
- Easy to mount
- Easy handling

SFP - 4Z



Extinguishing


- 1 extinguishing zone
- Easy to mount
- Easy handling

SFP - EXT1



Extension Modules:

SFP – 12R



12 relay card

- Fixed signal on each relay
- Switch over contacts 30V DC
- For fire alarm cards: Alarm 1-4
- For extinguishing cards:
 - Extinguishing actuator active
 - Evacuation status
 - Inhibition status
 - Manual mode

SFP – 4R



4 relay card

- Routing of the open collector outputs to relay
- Switch over contacts 230V

Certification:

